

Basic Manual



A5516T

by TOSHIBA

au by KDDI

Contents/
Getting Ready

Making and
Answering Calls

Character Input

Phone Book

Pair Function

Mail

Camera

EZweb

EZ Navi

Limit Mode

Smart Mode

Others/Index

Introduction

Thank you for purchasing the A5516T. Before using your A5516T, be sure to read the A5516T Basic Manual (this PDF manual) to ensure correct usage. After you have finished reading this manual, store this PDF manual and the printed manuals in safe places so you can retrieve them whenever you need them.

Printed Manuals for the A5516T (Japanese)

The A5516T comes with the Basic Manual and Instruction Manual.

A5516T Basic Manual



Equivalent to this English PDF manual.

A5516T Instruction Manual



English version is not available.

The following manual is also available on the au homepage.

- Keyword searchable au Online Manual

(<http://www.au.kddi.com/manual/index.html>)

You can also access the au Online Manual from EZweb.

<EZweb Access>  ⇒  Top Menu

⇒  料金・申込・インフォ (Charges, Applications, and Information)

⇒ auオンラインマニュアル (au Online Manual)

Read this barcode (QR code) for an easy access to au Online Manual. ▶



Note

- The typeface and shape of fonts used for characters in the sample screens in this manual may differ from those used for characters in actual screens, or some characters may be omitted.

Cell Phone Etiquette

Etiquette for Cell Phone Use

- The cell phone always emits weak radio waves when power is on.
- Use the cell phone in an enjoyable and safe manner without forgetting to be considerate of others around you.

● The use of cell phones is not allowed in some places

- Do not use the cell phone while you are driving. Doing so is both dangerous and prohibited by law.
- Using a cell phone in an aircraft is prohibited by law. Be sure to turn the cell phone off.



● Radio waves from cell phones may interfere with medical electrical equipment

- Some people close to you in busy places such as crowded trains may be using a pacemaker. Turn the cell phone off in such places.
- Abide by the rules of hospitals and other medical institutions where it is forbidden to use or carry cell phones.



● Be considerate of where you use the cell phone and how loudly you talk

- Do not make calls from cinemas, theaters, museums, libraries, and other similar places. Turn power off or turn on manner mode to prevent others around you from being inconvenienced by ring tones for incoming calls or mail.



- Do not use the cell phone in places where you will be in the way of others.
- Move to areas where you will not inconvenience others on trains or in hotel lobbies.
- Take care to avoid talking in a loud voice.



- Obtain the permission of other people before you take their photos with the cell phone's camera.



- Do not use the cell phone's camera for recording information in bookstores and other locations where taking photos is not permitted.

Cell Phone Basics

Cell Phone Features

Making/ Answering Calls

Your cell phone is packed with useful features such as phone book, call history, and manner mode.



Page
26

Limit Mode/ Smart Mode

You can select a mode that restricts operation, or a mode that allows simplified operation.

Pages
84,90



Camera

You can take photos and movie clips and then send them easily by e-mail.



Page
63

Mail

You can send mail to other cell phones and personal computers.



Page
50

EZ Navi

Provides useful positional information services including EZ Navi Walk, Position Search, and Area Message.

Page
78

EZweb

You can download "Chaku-Uta[®]," and access information sites.



Page
71

Manner Mode and Voice Memo

Manner Mode

You can use manner mode to turn off the incoming call ring tone and other tones so as not to inconvenience other people.



When the standby screen is displayed, hold down  (side key 2) for at least one second.

Page

30

Voice Memo

When you cannot answer calls, the cell phone can play an answering message (Japanese) and record memos.



When the standby screen is displayed, hold down  for at least one second.

Page

31

Checking the Power, Signal Strength, and Battery Level

Normally, you should leave the cell phone turned on



To make and receive calls, you need to turn on power.

Hold down  for at least one second.

Page

13

If a signal is not being received, you cannot talk on the cell phone



Even in service areas, there are some places where it is difficult to receive a signal.

 indicates the signal strength.

Page

13

Pay attention to the battery level



When the battery level is low, the cell phone may not function properly.

 indicates the battery level.

Page

13

Do not use the cell phone while driving!

Holding a cell phone, talking on a cell phone, looking at a cell phone display to send mail or perform some other operation while driving is against the law in Japan.

(Revised Traffic Control Law, effective November 1, 2004)



× Looking at mail on a cell phone display.



× Holding a cell phone in your hand for talking.

Turn off your cell phone or put it in Drive Mode while driving.

Drive Mode

In Drive Mode, a Japanese message meaning "I'm driving now, so I can't answer your call." is played when a call is received, telling the caller to leave a message on the voice memo.

When the standby screen is displayed, press  (side key 2), use  to select  *Drive Mode*, and then press  (Select).



Spam and One-ring Calls

If you receive spam:

You can set the mail filters to reject only specific mail or mail indicated by 未承諾広告※ (Unsolicited Advertisement), which often tends to be spam.

The following mail filters are available for rejecting spam:

- ・ 未承諾広告フィルター
(Unsolicited Advertisement Filter)
- ・ アドレスフィルター (Address Filters)
 - 指定拒否設定
(for not receiving specific mail)
 - 指定受信設定
(for receiving specific mail only)



Page

57

If you receive a call from an unknown phone number:

It may be an attempt to get you to return a call to a service with very high charges.



Incom History			
01	N	7/1	16:00
	030002XXXX		
02		6/30	15:35
	030001XXXX		
03		6/29	14:48
	Tom Daniels		
04		6/28	13:30
	090003XXXX		

 in the Incoming History indicates that there was a call which rang three seconds long or shorter.

Page

29

About Disaster Message Board

When a big scale disaster occurs, you can register your safety information through EZweb. The registered safety information can be referred from anywhere in Japan through EZweb or Internet.

Registering the safety information

- When a big scale disaster occurs, from a phone, you can register your safety information such as your condition or comments to the 災害用伝言板 (Disaster Message Board) created on the EZweb.
- After the registration of your safety information, you can notify by e-mail your family or acquaintances you have previously designated that you registered your safety information on the 災害用伝言板 (Disaster Message Board).

Referring the safety information


- You can refer to the safety information of the person whom you want to know the information of by entering the phone number of the person from EZweb or Internet.*
*When you refer to the safety information from other carriers' cellphone (except for TU-KA), PHS or PC, you can refer to it from "<http://dengon.ezweb.ne.jp/>".

Access

 ⇒  Top Menu ⇒ 災害用伝言板 (Disaster Message Board)


<http://dengon.ezweb.ne.jp/>

Top display of the Disaster Message Board




登録 for registration

Safety information registration display




Safety information reference display



確認 for reference

- The maximum preservation period of the registered information is 72 hours.
- The maximum available number of each registration is 10. When the number of registration exceeds 10, old information will be overwritten in order of registration.
- The demonstration of this service can be referred to anytime by pressing **[E]** ⇒ **[1]** **Top Menu** ⇒ **[7]** **料金・申込・インフォ** (Charges, Applications, and Information) ⇒ **災害用伝言板(デモ版)** (Disaster Message Board (Demo version)).
- To view the Disaster Message Board in English, select **English** on the top display of the Disaster Message Board.







Contents

● Introduction	
● Cell Phone Etiquette	1
Etiquette for Cell Phone Use	1
● Cell Phone Basics	2
Cell Phone Features	2
Manner Mode and Voice Memo	3
Checking the Power, Signal Strength, and Battery Level	3
Do not use the cell phone while driving!	4
Spam and One-ring Calls	5
Disaster Message Board Service	6
● Contents	8
● Getting Ready	10
Checking the Contents of the Box	10
Names of Parts	11
Charging the Battery Pack	12
Built-in Antenna	13
Turning On Power	13
Learning the Basics	14
Personal Identification Numbers and Passwords	16
Configuring Initial Settings	17
Switching the Display Language to English	18
Using Menus	19
Indicators	21
Initializing E-mail and EZweb	22
Checking Your Phone Number and E-mail Address	22
Changing Your E-mail Address	23
Using Extra Large Characters	25
● Making and Answering Calls	26
Making a Call	26
Answering a Call	27
Redialing (Outgoing History/Incoming History)	28
One-ring Calls	29
Turning On Manner Mode	30
Turning On Voice Memo	31
Playing a Voice Memo	32
Changing the Incoming Ring Tone	33
Adjusting the Incoming Ring Tone Volume	35
Adjusting the Earpiece Volume during a Call	36
● Character Input	37
Character Entry Modes	37
Entering Single-byte Alphanumeric Characters	37
Entering E-mail Addresses	39
Entering Pictograms	41
● Phone Book	42
Saving a Phone Book Entry	42
Dialing from the Phone Book	44
Editing Phone Book Entries	45
Saving a Phone Number from the Incoming or Outgoing History	46

● Pair Function	47
Registering a Pair Person	47
Making a Call to a Pair Person	48
Sending a Mail to a Pair Person	49
● Mail	50
Using E-mail	50
Creating and Sending E-mail Messages	51
Reading Received E-mail Messages	54
Reading an E-mail Message with an Attached Photo or Movie	56
Rejecting Spam	57
Replying to Received E-mail Messages	58
Using C-mail	60
Creating and Sending C-mail Messages	61
Reading Received C-mail Messages	62
● Camera	63
Camera Image Features	63
Photo and Movie Shooting Tips	64
Data Sizes	65
Taking a Photo	66
Recording a Movie	67
Viewing Photos or Movies	69
Attaching Photos or Movies to E-mail Messages	70
Photo Mail Service	70
● EZweb	71
What is EZweb?	71
Accessing Sites	72
Viewing the EZ Top Menu	73
Downloading Chaku-Uta®	74
Bookmarking Frequently Accessed Pages	76
Viewing Bookmarked Pages	77
Checking Charges	77
● EZ Navi	78
EZ Navi Features	78
What You Can Do with Position Search	80
What You Can Do with Area Message	81
Using EZ Navi Walk	82
Registering Your Home Location	82
Looking Up the Way Home	83
● Limit Mode	84
Changing the Limit Mode Password	84
Setting the Use Limit	86
Turning Limit Mode On and Off	88
Checking the Limit Mode Status of Use	89
● Smart Mode	90
Entering Smart Mode	90
Exiting Smart Mode	91
Viewing the Smart Menu	92
Saving a Phone Book Entry Using Smart Mode	94
Creating and Sending E-mail/C-mail Messages in Smart Mode	96
Using the Camera in Smart Mode	98
● Other Functions	100
● Troubleshooting	101
● Index	102


Names of Parts



Charging the Battery Pack

The battery pack is not fully charged at the time of purchase.

Be sure to charge the battery pack before using the cell phone for the first time.



* You can also charge the battery pack by connecting the Toshiba AC adapter 02 directly to the A5516T.

External power terminal

· Be sure to confirm the shape of the connector before connecting it to the external power terminal.

1 Connect the Toshiba AC adapter 02 to the desktop holder.

- After you confirm the shape of the connector, connect the Toshiba AC adapter 02 to the power terminal of the desktop holder.

2 Turn the Toshiba AC adapter 02's power plug 90 degrees and connect it to a 100 V AC power outlet.

3 While the A5516T is closed with the battery pack attached, insert it into the desktop holder as shown in the figure.

4 Confirm that the charge indicator lights red.

- Charging: The charge indicator lights red.
- Charging finished: The charge indicator goes out.

If you turn on power to A5516T and charge the battery pack, A5516T beeps when it starts or finishes charging.

Note


- Hold the desktop holder while removing the A5516T.
- Hold the lock-release buttons on both sides of the connector while removing the connector of the Toshiba AC adapter 02 from the desktop holder or A5516T.

Built-in Antenna

The antenna of the A5516T is built into its case.

Note

- Touching or covering the area around the built-in antenna may weaken a signal. In particular, do not affix any stickers or other decorations in the area around the built-in antenna.



Turning On Power

- 1 Hold down  for at least one second.



Check the signal strength.

				
Strong	Medium	Weak	Very weak	Out of range

- You cannot receive or make calls if  is displayed.

Check the battery level.

				
Full	Low	Very low (requires charging)	Empty	Charging

Standby screen



Turning Off Power

Hold down  for at least one second.

Learning the Basics

Key Assignments

 : Incoming History

 : Camera

 : E-mail

 : Make and answer calls; use the Pair function

   
: Phone number and character input



 : Outgoing History

 : Phone Book

 : EZweb

 : Voice memo setting/cancel; character delete; operation cancel


 : Power on/off; end call

 : EZapps startup

 : Mobile light on/off

 : Manner mode

 : Macro focus switch



Warp Function Key


Use the up, down, left, and right parts of the key to select items and to move the cursor. Press the center of the key to confirm a selected item.



	Selects items, and moves the cursor up, down, left and right.
	Confirms the selected item or starts the selected operation.

Soft Keys

When indications such as the following are displayed at the bottom of the display, you can press the corresponding soft keys to perform the indicated operations. The soft key indications vary depending on the screen.



Soft key 1 	Performs the operation indicated at the bottom left of the screen.
Center key 	Performs the operation indicated at the bottom center of the screen.
Soft key 2 	Performs the operation indicated at the bottom right of the screen.

If you lose track of where you are or if you make a mistake...

Perform one of the following operations when you lose track of where you are or if you make a mistake while operating the cell phone.



	Returns to the previous screen.
	Returns to the standby screen.

Personal Identification Numbers and Passwords

You can use the personal identification numbers and passwords described below to restrict use of your A5516T.

Take care not to forget the numbers and passwords, because they are required for performing various operations and using subscription services.

PIN

Usage Examples	①Remotely operating the answering service and call forwarding service from a regular phone. ②Making inquiries, applications, and changes while using au Customer Service Center voice guidance, au web pages, and EZweb. ③Changing various settings from <i>Other Setup</i> of E-mail Setup.
Initial Setting	The four-digit number you wrote on your subscription form.

Lock No.

Usage Examples	Changing various settings of the cell phone, etc.
Initial Setting	1234 (four digits)

Limit Mode Password

Usage Examples	①Setting/canceling Limit Mode. ②Changing the Limit Mode settings.
Initial Setting	12345678 (eight digits)

EZ Password

Usage Examples	Concluding/canceling subscriptions for EZweb fee-based content.
Initial Setting	The number (four digits) specified when first subscribing for fee-based content.

Premium EZ Password


Usage Examples	①Concluding/canceling subscriptions for EZweb fee-based content paid by using <i>まとめてau 支払い</i> (Combined au Payment Service). ②Purchasing products from EZweb sites that use <i>まとめてau 支払い</i> (Combined au Payment Service).
Initial Setting	The number (four to eight digits) specified the first time you use <i>まとめてau 支払い</i> (Combined au Payment Service).

Configuring Initial Settings

1 When the standby screen is displayed, press .



Initial menu



2 Press  **設定しない (Do Not Setup).**



Launcher menu



Note

- Even if you do not configure the initial settings, you can still make and answer calls.
- The initial settings include changing the lock number, setting the character size, setting the Notify Call ID, and setting the call ring tone.
- You need to configure initial settings before using the cell phone for the first time only. Furthermore, you can also change each of the initial settings later.
- After configuring initial settings, you can switch the display language to English (see page 18).
- If you select **設定しない (Do Not Setup)**, the initial settings are as shown below.

Lock No.	1234	EZweb	Small font
Telephone	Medium font	Character Input	Medium font
E-mail	Medium font	Notify Call ID	ON
C-mail	Medium font	Incoming Call Ring Tone	Pattern 1

Switching the Display Language to English

You can switch the display language for function names and other items to English.

- 1** When the standby screen is displayed, press .

→The Launcher menu appears.




- 2** Use  to select **機能** (Function) and then press  (**選択 [Select]**).



- 3** Press  **画面表示 (Display)**.

→The 画面表示 (Display) menu appears.




- 4** Press  **Set Language**.

→The Set Language menu appears.



- 5** Use  to select *English* and then press  (Select).



- 6** Use  to select *Alphabet* and then press  (Select).


→The display language is set to English.



Using Menus

Launcher Menu

The Launcher menu provides you with access to various A5516T functions. The Launcher menu contains the following items.



- 1** When the standby screen is displayed, press .



Launcher menu



Using Menus (continued)

2 Use  to select an item.



3 Press  (Select).

→ The item selected in the Launcher menu appears.



Note

- If the alert window is displayed on the standby screen, select  *Launcher Menu* and then press  to display the Launcher menu.

Alert window



Option Menus


An Option menu for performing various related operations will open if you press  when *Option* is displayed in a screen for configuring function settings, entering characters, or performing other operations.



 (Option)




 (Close)




Indicators

Display indicators keep you informed when new e-mail arrives, about the status of function settings, etc.



Indicator	Description
①	Indicates signal strength.
②	Indicates battery level.
③	Indicates that EZweb is in use.
③	Indicates a call is in progress.
③	Indicates that EZapps is in use.
④	Indicates an unanswered call.
⑤	Indicates received or unread e-mail/c-mail.
⑥	— Indicates the current date and time.
⑦	Indicates that the manner mode is turned on.
⑧	Indicates that the voice memo or manner mode is turned on.



Indicator	Description
①	Indicates signal strength.
②	Indicates battery level.
③	Indicates that the manner mode is turned on.
④	Indicates that the voice memo or manner mode is turned on.
⑤	Indicates new mail or an unanswered call.
⑥	— Indicates the current date and time.


Note

- The date and time are set automatically.
- The layout and content of screens in this manual are only for the purpose of explanation and contain some indicators that cannot appear at the same time.

Initializing E-mail and EZweb

To use e-mail and EZweb, you need to apply for an EZweb subscription. If you did not apply for an EZweb subscription at the time of purchase, contact an au shop or the au Customer Service Center. Also, before use, be sure to configure initial settings. Your e-mail address is assigned automatically when you initialize e-mail and EZweb.

- 1** When the standby screen is displayed, press .



EZwebを利用するための初期設定を行います
「OK」を押してしばらくお待ちください

- 2** Press  (OK).

→After a short while, the screen shown to the right will appear. This indicates that the setup is complete.



Welcome to EZweb.
Your e-mail address is:
△△△△△△△△△△△△@ezweb.ne.jp
-Hint-
If you want to change your e-mail address, push OK and enter a new e-mail address at e-mail menu → e-mail setting → others.

- 3** Press  (OK).

→The E-mail Menu appears.



Note

- You can also configure initial settings by pressing  or .

Checking Your Phone Number and E-mail Address

- 1** When the standby screen is displayed, press  and then press .


→Your phone number and e-mail address appear.



Profile MO
0900001XXXX
△△△△△△@ezweb.ne.jp

Changing Your E-mail Address

You can change the account name part of the e-mail address as indicated to the right.



1 When the standby screen is displayed, press and then press **E-mail Setup**.

→The E-mail Setup menu appears.



2 Press **Other Setup**, use to select **Yes**, and then press (OK).

→The cell phone connects to the server.



3 Use to select **Eメールアドレスの変更** (Change E-mail Address), press (Select), use to select the entry box, and then press (Edit).



4 Enter your PIN, press (OK), use to select **送信** (Send), press (Select), use to select **承諾する** (Accept), and then press (Select).



- Your PIN is the four-digit number you wrote on your subscription form.
- Any time the wrong PIN is entered three times during a single day, the e-mail address change operation will be disabled until the following day.

5 Use  to select the entry box, press  (Edit), and enter an e-mail address using single-byte alphanumeric characters.



みご入力ください。
? Eメールアド'は半角英数字20
文字まで入力可能です。
記号は「[]」のみ使用可能
です。「[]」は連続して利用し
たり、最初と最後には利用
できません。最初に数字の
「0」を使用することはできま
せん。

@ezweb.ne.jp

• For details on entering e-mail addresses, see page 39.

6 Press  (OK), use  to select 送信 (Send), and then press  (Select).



文字まで入力可能です。
記号は「[]」のみ使用可能
です。「[]」は連続して利用し
たり、最初と最後には利用
できません。最初に数字の
「0」を使用することはできま
せん。

@ezweb.ne.jp

送信 送信



新しいEメールアド'には
@ezweb.ne.jp

です。
よろしいですか?

アド'を変更した場合は変更
前のアド'を再度利用するこ
とはできません。

OK キャンセル

7 Use  to select OK and then press  (Select).



Update is complete.

• Check that the e-mail address has been updated and then press  (OK).

Note


• Your e-mail address will not be changed if the address you enter above is already being used. If this happens, enter a different e-mail address.

Using Extra Large Characters

Turning on extra large characters will display the names of callers and addressees on the Call Screen, the phone book list, etc.

- 1** When the standby screen is displayed, press .

→The Launcher menu appears.




- 2** Use  to select *Function* and then press  (Select).





- 3** Press  *Display*.

→The Display menu appears.



- 4** Press  *Character Size*.

→The Character Size menu appears.




- 5** Press  *Extra Large*, use  to select *ON*, and then press  (OK).



Making and Answering Calls

Making a Call

1 When the standby screen is displayed, use  to  to enter the phone number you want to call.



030001XXXX

- When calling to a regular phone, you also need to enter the area code even in the same area.

2 Press .

- If the phone number and name of the person you are calling are in the phone book, the name is also displayed.
- When you have finished the call, press .



Note

- After you enter a phone number, you can add 184 or 186 to the phone number if you press  (Option), press  Add/Off SP No..., and then press  184 or  186.
 - Select  184 if you do not want to inform the party you are calling of your phone number.
 - Select  186 if you want to inform the party you are calling of your phone number.

Answering a Call

1 To answer a call, press .

- When you have finished the call, press .



Display When a Call is Received

The phone number of the caller appears.

If the caller's phone number and name are in your phone book, the name is also displayed.

When the phone number of the caller is not displayed, one of the following indicators may appear.

Indicator	Meaning
ID Unsent	The caller did not send a Caller ID.
Pay Phone	The call is from a pay phone.
Not Support	The call is from a phone that does not support Caller ID.



Missed Call Notification

If you did not answer a call,  and  Call are displayed to let you know that you missed a call.

To check the caller's phone number, use  to select  Call and then press . You can then return the call (see page 28).



Redialing (Outgoing History/Incoming History)

Example: Returning a call to a phone number in the incoming history


1 When the standby screen is displayed, press .

- Pressing  while the standby screen is displayed displays the Outgoing History screen.
- The phone numbers are displayed in order of the most recent to the oldest.



2 Use  to select the phone number you want to call and then press  (Info).

- If you press  (→OutH), the Outgoing History screen will be displayed.



3 Press  (Call) or .



Note

- The cell phone can store up to 20 phone numbers in each of the incoming history and outgoing history in order of the most to least recent.


One-ring Calls

What is a One-ring Call?

A one-ring call is a call from an unknown caller that only rings once, causing it to be stored in the incoming history. One-ring calls are often used to get the receiver to return the call, which will connect you to a dating service or some other service that charges caller at high rates.

One-ring Indicator

 indicator on the display indicates you have received a one-ring call (a call rang for three seconds or shorter) and the call is marked with **Absnt** on the incoming history screen. Be careful when you return a call to an unknown caller.




Turning On Manner Mode

The cell phone informs you of a call by vibrating.

1 When the standby screen is displayed, hold down  (side key 2) for at least one second.


➔ This turns on manner mode, and displays  and  on the standby screen. This also turns on voice memo, which is indicated by  on the standby screen.



Turning Off Manner Mode

When the standby screen is displayed, hold down  (side key 2) for at least one second.

➔ Turning off manner mode causes  and  to disappear from the standby screen. Voice memo is also turned off, which is indicated by  disappearing from the standby screen.



Note

- The cell phone will continue to emit the record start/end tone and shutter sound during camera use even when manner mode is turned on.

Turning On Voice Memo

1 When the standby screen is displayed, hold down  for at least one second.

→The answering message (Japanese) is played, then voice memo is turned on, which is indicated by  on the standby screen.



Turning Off Voice Memo

When the standby screen is displayed, hold down  for at least one second.

→Voice memo is turned off and  disappears from the standby screen.




Note

- The cell phone can record a maximum of three messages, each up to 30 seconds long.
- The cell phone can record up to a total of three voice memos including call voice memos. A call voice memo is for recording the voice of the other party during a call.
- Voice memo is a function that automatically answers calls and allows callers to record messages. Use the answering service when your phone is turned off or when you are in a location where a signal cannot be received.

Playing a Voice Memo

If a voice memo is recorded

→  *Memo* and the number of memos appear on the standby screen.



- 1 Use  to select  *Memo* and then press .

→ The Play Voice Memo list appears.



- 2 Use  to select the voice memo you want to play and then press  (Play).

• To stop playing the voice memo, press  (Stop).



Deleting a Voice Memo

On the Play Voice Memo list, use  to select the voice memo you want to delete.

- Press  (Option) and then press  *Delete*.
- Use  to select *Delete One* and then press  (Select).
- Use  to select *Yes* and then press  (OK).


Changing the Incoming Ring Tone

1 When the standby screen is displayed, press .

→The Launcher menu appears.



2 Use  to select *Function* and then press  (*Select*).



3 Press  *Sound/Vibrator*.

→The Sound/Vibrator menu appears.




4 Press  *Incoming Call*.

→The Incoming Call menu appears.



5 Press  *Melody*.


→The Melody menu appears.



Changing the Incoming Ring Tone (continued)

- 6** Use  to select *Fixed Pattern* and then press  (**Select**).

→The Fixed Pattern menu appears.



- 7** Use  to select *Pattern 3* and then press  (**Play**).

- If you press  (Back) or , the tone stops playing and you can select another tone.



- 8** Press  (**OK**).

→The incoming ring tone is set.

**Note**

- You can select from among fixed patterns, fixed melodies, effect sounds, data folder contents, and EZweb search for your ring tone.
- The initial default setting is the *Pattern 1* fixed pattern.

Adjusting the Incoming Ring Tone Volume

1 When the standby screen is displayed, press .

→ The Launcher menu appears.




2 Use  to select *Function* and then press  (Select).



3 Press  *Sound/Vibrator*.

→ The Sound/Vibrator menu appears.




4 Press  *Incoming Call*.

→ The Incoming Call menu appears.



5 Press  *Volume*.

→ The screen for adjusting the ring tone volume appears.



Adjusting the Incoming Ring Tone Volume (continued)

6 Use  to adjust the volume and then press  (OK).



- Each press of  changes the volume one step.

	After a vibration alert, the ring tone sounds while gradually increasing in volume.
STEP DOWN	The ring tone sounds while gradually decreasing in volume.
STEP UP	The ring tone sounds while gradually increasing in volume.
 Maximum  ↑  Standard  ↓  Minimum	The ring tone sounds at the set volume.
 (Silent)	The incoming ring tone does not sound.

- Keep on pressing  to set Silent (.

Adjusting the Earpiece Volume during a Call

During a call, you can use Loud Volume or adjust the earpiece volume to one of five levels (1 to 5).


1 During a call, press .

→ The Speaker Volume screen appears.

: Increases the volume.

: Decreases the volume.

Turning on  Loud (Loud Volume) will increase the volume of the earpiece output to make it easier to hear.



2 Press  (OK).



Note

- Loud Volume can be used only during a call.


Character Input

Character Entry Modes

When a character entry screen is displayed, you can select the character entry mode if you press .

Menu Items

- Kanji : Kanji conversion mode
- a A : Double-byte alphanumeric mode
- abAB : Single-byte alphanumeric mode
- 1 2 : Double-byte number mode
- 1234 : Single-byte number mode



Use  to select a character entry mode and then press  (Select).

Entering Single-byte Alphanumeric Characters

You can use the keys  to  to enter characters. More than one character is assigned to each key.

For example, each press of  changes the displayed character to the next character assigned to the key in the order of a ⇒ b ⇒ c ⇒ A ⇒ B ⇒ C ⇒ 2. The following table shows the key assignment for entering characters.

Key	Number of Times to Press the Key											
	1	2	3	4	5	6	7	8	9	10	11	12
	.	@	—	—	/	:	~	?	,	'	!	1
	a	b	c	A	B	C	2					
	d	e	f	D	E	F	3					
	g	h	i	G	H	I	4					
	j	k	l	J	K	L	5					
	m	n	o	M	N	O	6					
	p	q	r	s	P	Q	R	S	7			
	t	u	v	T	U	V	8					
	w	x	y	z	W	X	Y	Z	9			
	0											
	Single-byte symbols (switches an unconfirmed character between uppercase and lowercase)											
	Adds a line break and displays characters in the opposite order											

When you change your e-mail address, you cannot use the characters in  for the account name (part of the address to the left of @).

Note


- Before you enter single-byte alphanumeric characters, switch to the single-byte alphanumeric mode.

Entering Two or More Characters Assigned to the Same Key


After you enter the first character, press  to move the cursor () to the right and then enter the next character.

Example: Entering "ab"


Press  once.



Press  once.



Press  twice.



Deleting Characters

To delete one character at a time, move the cursor to the character you want to delete and then press . To delete all characters to the right of the cursor, hold down  for at least one second. If there are no characters to the right of the cursor, holding down  will delete all the characters.

Starting a New Line

Press .

Note

- Certain functions such as c-mail do not support entering new lines.

Entering E-mail Addresses

E-mail Address Compatible Characters

- Before you enter an e-mail address, switch to the single-byte alphanumeric mode.
- When changing your e-mail address, you can enter up to 20 single-byte alphanumeric and symbol characters for the account name (part to the left of @). Note the following:
 - Uppercase characters cannot be used.
 - Two or more periods (.) cannot be used in succession.
 - Zero (0) cannot be used as the first character.


How to Enter E-mail Addresses

Use to to enter characters and numbers.

Example: Entering "taro.23@toshiba.co.jp" for the recipient's e-mail address

1 Enter "taro.23".

- t : Press once.
a : Press once.
r : Press three times.
o : Press three times.
. : Press once.
2 : Press and then press once.
3 : Press and then press once.



2 Enter "@".

- @ : Press twice.




3 Enter "toshiba" and then press (OK).

- t : Press once.
o : Press three times.
s : Press four times.
h : Press twice and then press .
i : Press three times.
b : Press twice and then press .
a : Press once.



4 Press  (abAB) and then press  *Phrase*.

→The category list appears.



5 Use  to select *Internet* and then press  (Select).

→The sentence list appears.



6 Use  to select *.co.jp* and then press  (Select).

→".co.jp" is entered.




Note

• To enter ".co.jp" etc., you can use the Sentence menu.

Entering Pictograms


1 When a character entry screen is displayed, press (abAB).

- ➔The character entry mode menu appears.
 - You can also enter symbols, emoticons, and useful sentences (fixed text) from the character entry mode menu.



2 Press .

- ➔The Pictogram screen appears.
 - You can switch the Pictogram screen by category, such as Face, if you press  or .



3 Use to select the pictogram you want to enter and then press (Select).

- ➔This enters the pictogram.
 - You can enter pictograms consecutively if you press  (Repeat) instead of  (Select).
 - Pictograms are not displayed properly on non-au cell phones, personal computers, and other devices.



Phone Book


Saving a Phone Book Entry



Hold down **B**
for at least one second.




New screen



- 1 Use **⊙** to select **Na me** (Name) and then press **⊙** (Select).

→The Name entry screen appears.



- 2 Enter a name and then press **⊙** (OK).

→The **Ke** (Reading) for the name is entered automatically.

- For details on entering characters, see page 37.



- 3 Use **⊙** to select **☎** (Tel. #1) and then press **⊙** (Select).

→The Tel. #1 entry screen appears.



- 4 Enter a phone number and then press **⊙** (OK).

→The Tel. #1 Class menu appears.

- If the phone number is for a regular phone, enter the phone number starting with the area code.




5 Use to select a phone number class and then press (Select).



→The New screen reappears.

- Follow the next two steps to enter an e-mail address. If you do not want to enter an e-mail address, proceed to Step 8.

6 Use to select (E-mail 1) and then press (Select).



→The E-mail 1 entry screen appears.

7 Enter the e-mail address, press (OK), select a class, and then press (Select).



→The New screen reappears.

- For details on entering e-mail addresses, see page 39.

8 Press (Add) and then press (Add).



→This saves the data to memory No. 000.

Note

- The cell phone automatically saves a maximum of 500 entries to the lowest available memory number from 000 to 499.
- You can save two phone numbers and two e-mail addresses for each phone book entry.
- You can also assign a group, and enter address, birthday, URL, and other information.

Dialing from the Phone Book

- 1 When the standby screen is displayed, press  to display the phone book name list.



- 2 Use  to select the entry containing the phone number you want to dial and then press  (Select).




- 3 Press .




Editing Phone Book Entries



Select the entry you want to edit and press (Select).



1 Press (Option) and then press *Edit*.



Phone Book

2 Edit the contents and then press (Add).




3 Use to select *Overwrite* and then press (OK).




Saving a Phone Number from the Incoming or Outgoing History

Example: Saving a phone number from the incoming history to the phone book

- 1 When the standby screen is displayed, press  and use  to select the phone number you want to save.



- 2 Press  (Option) and then press  *Add to Ph Book*.



- 3 Use  to select *New* and then press  (Select).



- For details on saving a phone book entry, see page 42.
- To open the Outgoing History screen for saving a phone number to the phone book, press  in Step 1.

Pair Function

You can register a maximum of five pair persons you contact often to easily call or send mail.

Registering a Pair Person

1 When the standby screen is displayed, press .


→The pair person screen appears.



2 Use  to select the *NO entry* screen and then press  (Add).

→The Add•Change menu appears.

- If you select the already-registered pair person, press  (Change) and you can either select *Edit* to edit the registered contents or select *Cancel* to cancel the pair person.



3 Use  to select *New* and then press  (Select).

→The New screen appears.

- You can also use  to select *Use Phone Book* to register a pair person.



4 Perform the procedure under "Saving a Phone Book Entry" on page 42.


Note

- The member that you register in the Pair function is also registered in the phone book.
- When you delete the phone book entry registered in the pair person, the phone book entry is also deleted from the Pair function.

Making a Call to a Pair Person

1 When the standby screen is displayed, press .

→The pair person screen appears.



2 Use  to select the person you want to call.



3 Use  to select *Call* and then press  (Select).

- When you select *Check*, you can confirm the registered contents including the phone number.




Note

- Even if the multiple of phone numbers and e-mail addresses are registered in the phone book, you can only use the phone number and e-mail address specified in *Tel. #1* and *E-mail 1*.


Sending a Mail to a Pair Person

1 When the standby screen is displayed, press .

→The pair person screen appears.



2 Use  to select the person you want to send a mail.




3 Use  to select *E-mail* or *C-mail* and then press .

- To create an e-mail message, see "Creating and Sending E-mail Messages" on page 51. To create a c-mail message, see "Creating and Sending C-mail Messages" on page 61.
- To confirm the registered contents of the pair person, select *Check*.




Create Mail screen (for e-mail)



Using E-mail

To use e-mail, you need to apply for an EZweb subscription. If you did not apply for an EZweb subscription at the time of purchase, contact an au shop or the au Customer Service Center. Also, before use, be sure to configure initial settings.

You can send and receive e-mail with another cell phone that supports e-mail, or with a computer. In addition to text messages that can contain up to 5,000 double-byte (or 10,000 single-byte) characters, you can also send photos and movies by e-mail.




- * You can send an e-mail message to up to five different addressees at one time.
- * You can send up to 1,000 e-mail messages per day (a message with multiple recipients is counted as more than one message).

Creating and Sending E-mail Messages

- 1** When the standby screen is displayed, press  and then press  *Create New*.

➔The Create Mail screen appears.



- 2** Use  to select *To* and then press  (**Select**).

➔The Address List screen appears.




- 3** Press  (**Option**) and then press  *Use Phone Book*.

➔The phone book name list appears.
• You can specify up to five addresses for the To, Cc, and Bcc fields.



Mail

- 4** Use  to select an addressee, press  (**Select**) and then press  (**OK**).




- 5** Press  (**OK**).



6 Use  to select *Subject* and then press  (Select).

→The Subject entry screen appears.




7 Enter a subject and then press  (OK).

• You cannot enter single-byte Japanese characters or a new line in a subject.




8 Use  to select *Text* and then press  (Select).

→The Text entry screen appears.




9 Enter the text of the message and then press  (OK).

• You cannot enter single-byte Japanese characters in the text of a message.



10 Press (Send).

→The Way of Send menu appears.



11 Use to select *Send* and then press (Select).

→The animation for sending e-mail is displayed and the e-mail message is sent.



Note

- You can also display the Sent History (Outgoing History) and use it to select an addressee, or enter the e-mail address directly.
- マイ絵文字送信 (My Pictogram) and おてがる絵文字送信 (Easy Pictogram) are fee-based services. To use these services, you need to apply for the separate 絵文字め〜る (Pictogram Mail) subscription for EZweb content.

Reading Received E-mail Messages

When you receive an e-mail message

→  *Email* appears on the standby screen along with the number of messages received.



1 Use  to select  *Email* and then press .

→ The Inbox opens.




Indicators

 : Indicates a folder containing a new message.

2 Press  (Select).

→ The Main Folder opens.



Indicators

 : Indicates a read message.

 : Indicates an unread message.


 : Indicates a message that has an attachment.

3 Use  to select the new message and then press  (Select).

→ You can read the message.



Viewing a Received Message




Note

- The procedure may differ depending on the e-mail settings.

Changing the Text Size

While an e-mail message is displayed, you can press **アプリ** to temporarily change the size of the displayed text (One-touch Text Size Switching).



Reading an E-mail Message from the E-mail Menu

When the standby screen is displayed, press **☑** to display the E-mail Menu and then press **2 abc** *Inbox*.

Indicators

📧 X/X : The number on the right of the indicator indicates the number of unread messages.



For subsequent operations, see "Reading Received E-mail Messages" (Steps 2 and 3 on page 54).

Reading an E-mail Message with an Attached Photo or Movie

Example: Viewing an attached photo

1 Display the e-mail message (page 54).



2 Use  to select the file name and then press  (Rcv).

→ This receives the photo.



3 Press  (Play).



Note

- Some files will already be displayed on the screen in Step 1, while other files will require that you select the file name, and then press  (Play) (Step 2). It depends on the file size.

Rejecting Spam

The setting of mail filters to reject spam is recommended.

Setting Mail Filters

When the standby screen is displayed, press .

➔ Press  *E-mail Setup*.

➔ Press  *Other Setup*.

➔ Use  to select *Yes* and then press  (OK) to connect to the server.

➔ Use  to select **メールフィルター** (Mail Filter) and then press  (Select).


➔ Use  to select the entry box and then press  (Edit).

➔ Enter your PIN and then press  (OK).

• Your PIN is the four-digit number you wrote on your subscription form.

➔ Use  to select **送信** (Send) and then press  (Select) to display the mail filters setting screen.

Mail filters setting screen



Unsolicited Advertisement Filter and Address Filters

1. 未承諾広告フィルター (Unsolicited advertisement filter)

Rejects mail that has a subject containing the expression "未承諾広告※" (Unsolicited Advertisement).

2. アドレスフィルター (Address filters)

全受信	All mail is received.
指定受信設定	This setting lets you specify sources from which messages can be received. You can select Internet and cell phone domain options (一括指定) and enter e-mail addresses, domains, and account names (part of the address to the left of @) individually (個別指定).
指定拒否設定	This setting lets you specify sources from which messages will be rejected. Enter e-mail addresses, domains, and account names (part of the address to the left of @) individually.
なりすまし規制	This setting lets you reject messages that appear to come from cell phones or PHS phones, but actually do not. You can use なりすまし規制 (Block Impostor) in combination with 全受信 (Receive All), 指定受信設定 (Receive Specific Mail Only), and 指定拒否設定 (Reject Specific Mail) settings. If you select the 規制する (Restrict) option while 全受信 (Receive All) is selected, for example, only messages made to appear like they come from cell phones or PHS phones, when they do not, are rejected.

* You can also configure a list of specific e-mail addresses for mail rejection after configuring 指定受信設定 (Receive Specific Mail Only).

Note

• You can also prevent spam by changing your e-mail address. For details on changing your e-mail address, see page 23.

Replying to Received E-mail Messages


- 1 When the standby screen is displayed, press  and then press  **Inbox**.

→The Inbox opens.



- 2 Press  (**Select**).

→The Main Folder opens.



- 3 Use  to select the message you want to reply to and then press  (**Select**).

→You can read the message.



- 4 Press  (**Reply**).

→The Create Mail screen appears. "Re:" is prefixed to the subject, and the text of the message is quoted.



5 Refer to "Creating and Sending E-mail Messages" (Steps 8 and 9 on page 52) and enter the text of the message.



6 Press  (Send).

→The Way of Send menu appears.



7 Use  to select *Send* and then press  (Select).


→The animation for sending e-mail is displayed and the e-mail message is sent.



Using C-mail

C-mail is a service that makes it possible to exchange messages between two au cell phones that support c-mail. A c-mail message can contain up to 50 double-byte (or 100 single-byte) characters.

Subscribers in the Kanto and Chubu areas do not need a separate subscription to use c-mail. For subscribers located outside of these areas, a separate subscription is required.



C-mail Safe Block Function


C-mail safe block function is a function that allows you to reject to receive c-mails that include accessing URL (<http://△△△>, <https://△△△>) or phone numbers in the c-mail message text.

C-mail safe block function is valid by default. You can cancel the setting if you want to receive c-mails that include accessing URL or phone numbers in the message text.

Creating and Sending C-mail Messages


- 1 When the standby screen is displayed, hold down  for at least one second, and then press  *Create New*.

→The Text entry screen appears.



- 2 Enter the text of the message and then press  (OK).

→The To menu appears.



- 3 Use  to select *Use Phone Book* and then press  (Select).

→The phone book name list appears.



- 4 Use  to select an addressee and then press  (Select) twice.

→The Create Mail screen appears.



- 5 Press  (Send).

→The animation for sending c-mail is displayed and the c-mail message is sent.



Note


- You can also display *Sent History* (Outgoing History) or *Received Hist* (Incoming History) and use it to select a recipient or enter the phone number directly.

Reading Received C-mail Messages

Received c-mail messages are saved to the Inbox.


When you receive a c-mail message

➔  Cmail appears on the standby screen along with the number of received messages.



1 Use  to select  Cmail and then press .

➔The Inbox opens.



Indicators

 : Indicates a read message.

 : Indicates an unread message.

2 Use  to select the new message and then press  (Select).

➔You can read the message.




Reading a C-mail Message from the C-mail Menu

When the standby screen is displayed, hold down  for at least one second to display the C-mail Menu, and then press  *Inbox*.

Indicators

 X/X : The number on the right of the indicator indicates the number of unread messages.



Use  to select the message you want to read and then press  (Select).

Camera

Your cell phone has a mega pixel camera (1,300,000 pixels available) that you can use to shoot photos and movies. It also has a self-timer for taking photos.

You can use images you record for the standby screen, and you can attach them to e-mail messages.

Camera Image Features


Using Images




Captured Images

You can use images for screens such as the standby screen and call screen, and you can include them in phone book entries.

Sending Images



You can attach images up to 280 KB in size to e-mail messages.



Note

- It may take time to send e-mail messages due to radio wave conditions.


Photo and Movie Shooting Tips

When shooting photos or movies, frame the subject within the display or sub display and hold the A5516T steady with both hands to avoid shaking.

Taking a Photo


Photo Mail, Wallpaper, and Multiple Modes

Orient the A5516T so  appears in the upper right of the display.



VGA and SXGA Modes

Orient the A5516T so  appears in the upper left of the display.




Orient the A5516T sideways when taking the photo.

While the Cell Phone is Closed

This feature is mainly for taking photos of yourself.

Orient the A5516T so  appears in the upper right of the sub display.




* The illustration shows how the camera is held when taking with VGA or SXGA mode.

Recording a Movie

Recording a Movie

Orient the A5516T so  appears in the upper left of the display.



Take care not to cover the microphone with your fingers during recording.

While the Cell Phone is Closed

This feature is mainly for recording a movie of yourself.

Orient the A5516T so  appears in the upper right of the sub display.



Certain recording conditions may result in the volume of the movie audio being too low to hear any sound during playback.


Data Sizes

When the Data Folder is used in the factory settings, the number of photos/movies you can capture is shown below if all the photos/movies are captured in the same mode. However, the following numbers may vary depending on photography/recording conditions.

Photo

(Factory setting: Wallpaper)

Mode	Photo Quality	Approximate Data Size per Image	Maximum Number of Images
PhotoMail	—	9 KB	500
Wallpaper/Multiple	—	30 KB	500
VGA	Fine Mode	120 KB	170
	Normal Mode	60 KB	341
	Mail Mode	40 KB	500
SXGA	Fine Mode	300 KB	68
	Normal Mode	170 KB	120
	Mail Mode	100 KB	204




- ① Photo Mail : 144 (W) x 176 (H) dots
- ② Wallpaper/Multiple : 240 (W) x 320 (H) dots
- ③ VGA : 640 (W) x 480 (H) dots
- ④ SXGA : 1,280 (W) x 960 (H) dots

Movie

(Factory setting: Std M (Mail))

Record Mode	Recording Time	Approximate Data Size per Image	Maximum Number of Movies
Std S (Mail)*	15 sec.	69 KB	292
Std M (Mail)*	15 sec.	83 KB	243
Std M (Video)*	150 sec.	800 KB	25

* The data size and number of movie values are average values for recording up to the allowable recording time per movie.



- ① Std S (Mail) : 96 (W) x 80 (H) dots
- ② Std M (Mail/Video) : 128 (W) x 96 (H) dots

Taking a Photo

1 When the standby screen is displayed, press .

- ➔ The monitor screen appears.
- To turn on the mobile light, press  (side key 1) while the monitor screen is displayed.



Monitor screen



2 Point the lens at the subject and then press (Shot) or (side key 2).

- ➔ The photo you just took appears (preview screen).



Preview screen



Saving a Photo

Press  (Save).

Note

- If you press  () while the monitor screen is displayed, the key-operation guidance screen will appear for approximately 15 seconds.
- Photos are saved to the Photo Folder in the Data Folder.
- If you do not want to save the photo, press  in the preview screen, use  to select *Yes*, and then press  (OK).
- The following shows how to read the file name in the Data Folder when you take a photo in the Wallpaper mode.

File Name Example : 050701_1234~01

Recording Date: July 1, 2005

Time: 12:34

Serial Number: Photo 1

Recording a Movie

1 When the standby screen is displayed, hold down  for at least one second.

- ➔ The monitor screen appears.
- To turn on the mobile light, press  (side key 1) while the monitor screen is displayed.



Monitor screen



2 Point the lens at the subject and then press  (Rec) or  (side key 2).

- ➔ The cell phone emits a recording start sound, and  REC lights when recording starts.



Stopping Recording

Press  (Stop).

When You Stop Recording or the Recording Time Elapses

The first frame of the movie you just recorded appears (preview screen).

Preview screen



Playing Back a Movie Before it is Saved

Press  (Option) and then press  Play.

Saving a Movie

Press  (Save).

Note

- If you press  () while the monitor screen is displayed, the key-operation guidance screen will appear for approximately 15 seconds.
- Movies are saved to the Movie Folder in the Data Folder.
- If you do not want to save the movie, press  in the preview screen, use  to select *Yes*, and then press  (OK).
- The following shows how to read the file name in the Data Folder when you record a movie in the Std M (Mail) mode.

File Name Example : 050701_123401

Recording Date: July 1, 2005

Time: 12:34

Serial Number: 1

Viewing Photos or Movies


Example: Viewing a photo

1 When the standby screen is displayed, press .

→The Launcher menu appears.




2 Use  to select *Data Folder* and then press  (Select).



3 Use  to select *Photo Folder* and then press  (Select).

→The Photo Folder opens.
• To view a movie, select *Movie Folder*.



4 Use  to select a folder and then press  (Select).

→The folder data appears.



5 Use  to select the photo you want to view and then press  (Play).

→The photo appears.
• You can attach the photo to an e-mail message by pressing  (Option) and  Attach E-mail.



Attaching Photos or Movies to E-mail Messages

1 While the preview screen is displayed after shooting a photo or movie, press  (E-mail).


- ➔ The photo or movie is attached to an e-mail message and the Create Mail screen appears.
- The  (Attachment) indicator changes automatically to , indicating that an image has been attached. For details on creating an e-mail message, see page 51.

Photo Mail Service

The Photo Mail Service automatically converts photos and movies so they can be viewed on a non-au cell phone.

When sending an e-mail message, select **フォトメール便送信** (Photo Mail Service) on the Way of Send screen.

This will automatically send the message to a special address.



Phone Company of Cell Phone	E-mail Address	E-mail Address after Change
DoCoMo	△△△@docomo.ne.jp	△△△@d.nepm.jp
Vodafone	△△△@□*.vodafone.ne.jp	△△△@□*.vodafone.nepm.jp
TU-KA and movie mail incompatible au cell phones	△△△@ezweb.ne.jp	△△△@ezweb.nepm.jp


* varies depending on the subscription region.

What is EZweb?

EZweb is an information service that allows you to enjoy using the Internet on your cell phone. You can also download Chaku-Uta®, news, and other data from information web pages.

To use EZweb, you need to apply for an EZweb subscription.

If you did not apply for an EZweb subscription at the time of purchase, contact an au shop or the au Customer Service Center. Also, before use, be sure to configure initial settings.




Note


- The layout and content of the screens in this manual are only for the purpose of explanation. The layout and content of actual screens may be different from the ones shown here.

Accessing Sites

Displaying the Top Menu



Use **[E]** to select the site you want to access and then press **[O]** (Select). Pressing **[O]** or **[RE/PVP]** returns to the previous screen. Holding down either key for at least one second returns to the Top menu.



Note

- The following describes the basic operations that are available while accessing sites.

Key Operation	Description
[←]	Exits EZweb and returns to the standby screen.
[O]	Moves the cursor up and down. When there is data available above or below the current screen, scrolls the screen line-by-line.
[E] , [D]	When there is data available above or below the current screen, scrolls the screen page-by-page. [E] : Scrolls one page up. [D] : Scrolls one page down.
[RE/PVP]	Returns to the previous screen.

- In addition to communication charges, some sites charge for providing information.

Viewing the EZ Top Menu

You can access EZweb from the Top menu. A variety of useful and fun sites are available on EZweb.

Top Menu



au style	Introduces information and sites that au recommends.
とくする情報	Presents gifts and push information to the EZweb subscriber for free.
最新情報	Provides an easy access to exclusive information and daily information including weather forecast and fortune telling.
EZサービスで探す	Introduces amusing and useful online services that EZweb offers.
カテゴリで探す	Searches sites by category.
1. ビジネス&ニュース	Provides the latest information, such as news, weather and stock prices, and other useful information for your business.
2. エリア	Provides local information including weather and maps.
3. ショッピング&オークション	Provides shopping and auction information that you can use from your cell phone.
4. ライフ	Provides useful information for daily living.
5. ホビー&カルチャー	Provides the latest information, such as games, fortune telling, and music, and popular information, such as hobbies and entertainment.
6. キーワードで探す	Sets search by keyword.
7. 料金・申込・インフォ	Provides information about charges, various applications, au online manual and notices from au.
災害用伝言板	Register and confirm safety information in time of disaster.
English	Introduces English sites.

Downloading Chaku-Uta®

- 1** When the Top menu is displayed (page 73), use  to select **カテゴリで探す** (Category Search) and then press  (Select).



→The カテゴリで探す (Category Search) screen appears.

- 2** Use  to select **着うた・着ムービー** (Chaku-Uta®/Chaku-Movie) and then press  (Select).



→The 着うた®・着ムービー (Chaku-Uta®/Chaku-Movie) screen appears.

- 3** Use  to select the site you want to access and then press  (Select).



→The download procedure appears.

- To use information sites that charge for providing information, you need to enter your EZ password or premium EZ password. If this is your first time to use such sites, you need to set each password.

EZ password: four-digit number you specify when you subscribe for fee-based content for the first time.

Premium EZ password: four-to-eight digit number you specify when you first use the Combined au Payment Service.

Follow the instructions on the display to specify each password.

- 4** Follow the instructions that appear on the display.

→Download is completed.



5 Press (Play).

- ➔The downloaded Chaku-Uta® plays.
- Downloaded data is saved automatically to the Data Folder.



6 During playback, press

 (Add).

- ➔The Register to where? menu appears.



7 Use to select the tone you want to use the Chaku-Uta® for and then press (OK).

- ➔The Chaku-Uta® is set as a tone.
- You can use the same operation to download an image and set it to the standby screen, etc.



Note

- This procedure is only an example for the purpose of explanation and may differ from actual procedures. Follow the instructions on the site from which you want to download the data.


Bookmarking Frequently Accessed Pages

You can save the titles and URLs you often visit, which makes it easy to return to them when you want.

1 When the page you want to bookmark is displayed, press

 (Browser).

→The Browser menu appears.



2 Press  *Add Bookmark*.

→The title and URL entry screen appears.

- Some pages cannot be bookmarked.



3 Press  (Add).

→The displayed page is bookmarked, and its title and URL are added to the Bookmark list.




Note

- The Bookmark list can contain up to 100 titles and URLs.

Viewing Bookmarked Pages

- 1** When the standby screen is displayed, press **[E]**.

→The EZ Menu appears.



- 2** Press **[2 abc]** *Bookmark*.

→The Bookmark list appears.



- 3** Use **[0]** to select the bookmark for the page you want to view and then press **[Access]**.

→The cell phone connects to the site and displays the page.



Checking Charges

You can use EZweb to check call charges, communication charges, and other information.


- 1** When the standby screen is displayed, press **[Access]**.

→The Launcher menu appears.



- 2** Press **[1 ああ]** **[1 ああ]** and then press **[Access]** (**OK**).

→The 料金照会 (Check Charges) screen appears. Select the items you want to check.



EZ Navi Features

Using GPS (Global Positioning System), EZ Navi provides useful positional information services.



Select *EZnavi* and then press (Select).



Position Search to check where your kids are

You can check the location of another au phone that supports Position Search from your A5516T. Position Search Mail and Auto Position Search services are available in Position Search.



- EZnaviwalk
- Position Search
- Area Message
- EZnavi Setup


Area Message to inform of your arrival in a specific area

When your A5516T enters (or goes out of) a specific area during a predefined time period, Area Message emits an alarm tone and automatically sends a message to another au phone you have specified.



EZ Navi Walk for when you go out

EZnaviwalk menu



Going-Out Menu



Displays menus that are useful when you are out.

Go Home

Search result screen



Select
ルート案内開始
(Start Route
Guidance).
⇒ Select
はい (Yes).
⇒ Select
はい (Yes).



Preset the location of your home, and you will be guided to your home wherever you are.

My Spot



Register your favorite locations, your home, etc. for quick and easy navigation whenever you need it.

Current Map


Map screen



★ represents your initial location. As you start moving, changes of your location are tracked by continuous positioning and indicated in real time by .

Selecting *Current Map* displays a map of your current location in real time.

Current Mail



When, for example, you have arranged to meet someone, you can send a message to let the person know your current location.


Note

• You need to pay packet transmission charges for using EZ Navi services.

What You Can Do with Position Search

Position Search enables you to check the location of your child at anytime by simple operations on your A5516T. Two types of services are available in Position Search: Position Search Mail (位置確認メール) and Auto Position Search (いつでも位置確認).

① Position Search Mail




【Features】

- You can send your child a message asking his/her current location.
- Your child can read your message and reply with a map of his/her current location.

Example: Sending position search mail to your child

② Auto Position Search



【Features】

You can check where your child is without requiring any operation on the side of your child. Auto Position Search is especially recommended when the child is too young to operate a cell phone.

- * A monthly fee payment is required for using this service.

Example: Searching for the location of your child

What You Can Do with Area Message

When your child enters (or goes out of) a specific area during a predefined time period, the cell phone he/she carries emits an alarm tone and automatically sends a message to your cell phone.

Area Message



[Features]

You do not have to worry about your child even when he/she is out alone. The cell phone that he/she carries automatically sends you a message when he/she passes the specified area on his/her usual way back home from school, etc.

Example: An area message tells your child has just passed the area.

Note

- Security Navi (Position Search and Area Message) services are available only between au cell phones that are compatible with those services.
- A separate packet transmission charge is required to be paid for obtaining positional information and displaying maps.
- Before using the Security Navi services, you must read and agree with their terms of services.
 - * Note that it is also necessary for the other party with whom you are using the services to agree with the same terms of services.
- You need to set an EZ Navi password to start using the Security Navi services.
- Position Search is not available in such cases as when the cell phone you are searching for is out of range, rejecting to be searched or operating some other application; or when it is no longer compatible with Position Search because the relevant application has been deleted, etc.
- The screen images shown in this manual are only examples and may be different from the actual display.
- You cannot use the Security Navi services when c-mail function is suspended.
- Family Discount plan for c-mail and Packet Discount plan do not apply to the area message transmission charges.

Using EZ Navi Walk

① Registering Your Home Location



② Looking Up the Way Home



Note


- Before use, be sure to configure initial settings. If you have not yet configured initial settings, see page 22.
- EZ Navi Walk includes free menus and those of fee-based services for which a separate subscription is required.
- The layout and content of the screens in this manual are only for the purpose of explanation. The layout and content of actual screens may be different from the ones shown here.

Registering Your Home Location

Example: Registering your current location as "Home"

- 1** From the EZnaviwalk menu (page 79), press **2** か abc *My Spot*.


➔ The My Spot menu appears.



- 2** Use **Ⓞ** to select *Home*, press **Ⓞ** (Option), and then press

1 あ い *Add GPS Info*.

➔ The Select GPS Info menu appears.



- 3** Use  to select *Current Point*, press  (Select) to obtain the GPS information, and then press  (OK).



→Your current location is registered as your home.

Looking Up the Way Home

Using this feature makes it easy to navigate from your current location to the location indicated by GPS information you registered as your home using My Spot.

- 1** From the EZnaviwalk menu (page 79), press  *Go Home*, use  to select *はい* (Yes), and then press .



→The route search result appears.

- 2** Use  to select *ルート案内開始* (Start Route Guidance), press , use  to select *はい* (Yes), and then press .




→A map of your current location appears and the map scrolls automatically in accordance with your movement.

Limit Mode

Limit Mode allows parents or superiors to impose limits on how much each function can be used. This helps to prevent overuse of the cell phone by their offspring or subordinates. Restrictions can be placed on incoming and outgoing calls, incoming and outgoing e-mail and c-mail, EZweb use, and EZapps* use.

* Including EZ Navi Walk, Position Search, and Area Message.

Displaying the Limit Mode Screen



Changing the Limit Mode Password

The Limit Mode password protects against unauthorized modification of Limit Mode settings.

- 1 On the Limit Mode screen (above), press **4** *Limit Mode Setup*.



- 2 Enter the current Limit Mode password and then press **(OK)**.



- The initial default password is "12345678".
- If you registered a hint to help you remember the password, press **(Hint)** to display it.

- 3** Use  to select *Password Setup* and then press  (**Select**).



- 4** Enter the current Limit Mode password and then press  (**OK**).



- 5** Enter the new password and then press  (**OK**).

- This registers the new password and displays the hint confirmation screen.
- The new password can be anywhere from one to eight digits long.



- 6** Use  to select *Yes*, press  (**OK**), enter the hint, and then press  (**OK**).

- If you do not want to enter a hint, select *No* and then press  (**OK**).



Note

- For the hint, enter something that will help to remind you of the password.
Example: Password :20051224
Hint :Day I bought A5516T

Setting the Use Limit

You can configure the cell phone to prohibit outgoing calls and mail send if a monthly use limit amount is exceeded.

- 1** On the Limit Mode screen (page 84), press **4** た ghi **Limit Mode Setup**.



- 2** Enter the current Limit Mode password and then press **(OK)**.




- If you registered a hint to help you remember the password, press **(Hint)** to display it.




- 3** Use **(OK)** to select **Limit Setup** and then press **(Select)**.




- 4** Use **(OK)** to select **Time · Use** and then press **(Select)**.




5 Use  to select *Use Limit* and then press  (Select).



6 Use  to select *Call* and then press  (Select).



7 Use  to select *Limited* and then press  (Select).



8 Enter the call limit amount and then press  (OK).



Note

- In addition to the limit by the amount of use, you can also limit use of specific functions (Access Limit), and use during a specific time period (Time Zone Limit).

Turning Limit Mode On and Off


- 1 On the Limit Mode screen (page 84), press **5** *Limit·Cancel*.



- 2 Enter the current Limit Mode password and then press **OK**.



- If you registered a hint to help you remember the password, press **Hint** to display it.




- 3 Use **OK** to select *ON* and then press **OK**.




Checking the Limit Mode Status of Use

- 1** On the Limit Mode screen (page 84), press **2** か abc *This·Last Mth Use.*



- 2** Use  to select *Call* and then press  (**Select**).

- Press  (LstMth) to display rough figure of last month's usage.



Note

- Figures of usage displayed are not accurate and should be used only as a guide.

Smart Mode

Setting Smart Mode enables limited and simplified operations of the phone function, phone book, camera, mail, EZweb and other often-used functions.


Entering Smart Mode

1 When the standby screen is displayed, press .


→ The launcher menu appears.



2 Use  to select *Smart Mode* and then press  (Select).



3 Use  to select *ON* and then press  (OK).



4 Use  to select *Yes* and then press  (OK).

→ This enters Smart Mode.



Note

- Entering Smart Mode causes some settings that were previously configured to change to Smart Mode settings.

Exiting Smart Mode


1 When the standby screen is displayed, press .

→The Smart menu appears.




2 Use  to select *Function* and then press  (Select).

→The Set Function menu appears.



3 Use  to select *Exit SmartMode* and then press  (Select).



4 Use  to select *Yes* and then press  (OK).

→This exits Smart Mode.



Viewing the Smart Menu

The Smart menu contains the following items.



Indicator	Function Name	Description	
	Call	See Phone Book	Phone book number recall for dialing
	Call	See incom hist	Calling History recall for dialing
		See outgo hist	
		Add Phone Book	Phone book data registration (P.94)
		See my number	Display of own phone number and e-mail address
	Mail	E/C-mail creation/reading (P.96)	
	Camera	Photo/movie recording (P.98)	
	Data Folder	Data folder data and photo/ movie file display/playback (P.99)	
	Alarm	Alarm sounds at preset time.	

Indicator	Function Name	Description
	Volume	Call ring tone setting
	Melody	
	Standby Screen	Standby screen setting
	Character Size	Display character size setting
	Manner Mode	Normal manner mode setting
	Memo	Voice memo setting
	Exit SmartMode	Voice recorder recording
	My Number	Smart Mode exit (P.91)
		Display of own phone number and e-mail address


Saving a Phone Book Entry Using Smart Mode

- 1** When the standby screen is displayed, press .




- 2** Use  to select *Yes* and then press  (OK).

→The Name entry screen appears.



- 3** Enter a name and then press  (OK).


→The phone number input method menu appears.



- 4** Use  to select *Input* and then press  (Select).

→The phone number input screen appears.

- If you do not want to enter a phone number, press  (OK) and proceed to Step 6.
- You can also use  to select *See Incom Hist* or *See Outgo Hist* and enter a phone number from there.



- 5** Enter a phone number and then press  (OK).

→The e-mail address input method menu appears.


- If the phone number is for a regular phone, enter the phone number starting with the area code.



6 Use to select *Input* and then press (Select).

→The e-mail address input screen appears.


- If you do not want to enter an e-mail address, press  (OK) and proceed to Step 8.
- You can also use  to select *See Sent Hist* or *See rcv hist* and enter an e-mail address from there.



7 Enter an e-mail address and then press (OK).

→The New screen appears.

- You can use  to select an item and then press  (Edit) to edit something you have already entered, or to configure call ring tone and mail ring tone settings.



8 Press (Add).

→The entry is saved in the phone book.



Note

- When you have already stored data in the phone book, pressing  while the standby screen is displayed displays a phone book list. To store new phone book data, press  (New) and perform Steps 3 through 8 of the above procedure.
- To edit phone book contents, press  while the standby screen is displayed. Use  to select the phone book entry you want to edit, press  (Select), and then press  (Edit).
- For other details, see page 42.

Creating and Sending E-mail/C-mail Messages in Smart Mode

Example : Creating and sending an e-mail message


1 When the standby screen is displayed, press .

→The Select Mail menu appears.




2 Use  to select *E-mail* and then press  (Select).

- To create a c-mail message, select *C-mail*. With c-mail you enter the text first and then enter the address.



3 Use  to select *Create Mail* and then press  (Select).

→The Address input method menu appears.




4 Use  to select *See Phone Book* and then press  (Select).

- The phone book list appears.
- You can specify only one address.
- Only entries that include an e-mail address are displayed.
- You can also use  to select *See sent hist*, *See rcvd hist* or *Input* and select an address from there.




5 Use  to select the recipient you want to send to and then press  (Select).

→The Subject input screen appears.



6 Enter a subject and then press (OK).

➔The Text entry screen appears.



7 Enter the text of the message and then press (OK).

➔The Create Mail screen appears.

- You can edit the currently selected item by pressing  (Edit). You can also save the mail message in the Outbox by pressing  (Save).
- You can attach a photo or other data in the Data Folder by using  to select *Attachment*. You can also change or remove the current attachment. A mail message can have only one attachment.



8 Press (Send).

➔The animation for sending e-mail is displayed and the e-mail message is sent.




Using the Camera in Smart Mode

Taking a Photo

1 When the standby screen is displayed, press .

→ The Camera menu appears.



2 Use  to select *Take A Picture* and then press  (Select).

→ The monitor screen appears.

- You can change the mode by pressing  (Size).



3 Point the lens at the subject and then press  (Shot) or  (side key 2).

→ The photo you just took appears (preview screen).



Saving a Photo

Press  (Save).

Note

- When you select *Digi Camera* in Mode menu, a photo is taken in the SXGA size.

Viewing a Photo

- 1** When the standby screen is displayed, press .

→The Smart menu appears.




- 2** Use  to select *Data Folder* and then press  (Select).

→The Data Folder menu appears.



- 3** Use  to select *Photo Folder* and then press  (Select).

→The Photo Folder opens.



- 4** Use  to select a folder and then press  (Select).

→The folder data appears.



- 5** Use  to select the photo you want to view and then press  (Play).

→The photo appears.



Other Functions

In addition to the functions covered in this Basic Manual, the A5516T also has the following features.

Only Mail

You can send a message with a movie or photo attachment to a specific recipient without opening the A5516T.

Cuckoo Clock

A movie is played on the sub display to inform you of the time, every hour on the hour.

EZ Chaku-Uta®

You can specify the actual song of a particular artist as an incoming ring tone.

Movie Setting

You can specify a movie you recorded as an incoming ring tone or incoming screen.

Edit Movie

You can add subtitles (two lines of 10 characters each) and record a voiceover after recording a movie.

EZapps (BREW®)

You can enjoy using various applications including large-volume games that are rich in expressive content, and standby applications.

Photo Mixer

You can use an animation template with melody to create your own original animation from a mixture of photos and text. You can attach animations to e-mail messages.

Voice Recorder

You can record voice memos while the cell phone is in standby. This feature comes in handy for recording during a meeting of seven or eight people, when having a discussion with few people, etc.

Troubleshooting

Symptom	Check	Measure	Reference Page
Cannot turn on power.	● Is the battery pack charged?	Charge the battery pack.	12
	● Did you hold down  for at least one second?	Hold down  for at least one second.	13
Cannot make calls.	● Is power turned on?	Hold down  for at least one second.	13
	● Is  (out of range indicator) displayed?	Move to a location where  (out of range indicator) is no longer displayed, and try again.	13
	● Is your hand covering the area around the built-in antenna?	Make sure your fingers or any other part of your hand is not touching or covering the area around the built-in antenna.	13
	● Did you enter the phone number starting with the area code?	When making a call to a phone other than a cell phone, you need to enter the area code first even if you are inside the same area.	26
Cannot receive calls.	● Is  (out of range indicator) displayed?	Move to a location where  (out of range indicator) is no longer displayed.	13
	● Is power turned on?	Hold down  for at least one second.	13
No response when a key is pressed.	● Is power turned on?	Hold down  for at least one second.	13
A warning tone sounds and power turns off.	● Is there enough power left in the battery pack?	Charge the battery pack.	12
Calls are answered automatically.	● Is voice memo turned on?	Hold down  for at least one second to turn off voice memo.	31
Cannot hear the other party.	● Is the earpiece volume level too low?	During a call, press  to increase the earpiece volume.	36
When making a call, a beeping sound is heard from the earpiece and a connection cannot be established.	● Is  (out of range indicator) displayed? Or are you in a location where the signal is too weak?	Move to a location where  (out of range indicator) is no longer displayed.	13
	● Is the wireless line congested or is the phone you are calling busy?	End the call and try again later.	26
The incoming indicator flashes but the ring tone does not play.	● Is manner mode turned on?	Hold down  (side key 2) for at least one second to turn off manner mode.	30
	● Is  (silent indicator) displayed on the standby screen?	Increase the volume of the incoming call ring tone.	35
Cannot charge the battery pack.	● Is the Toshiba AC adapter 02 plugged into a power outlet?	Insert the adapter in the power outlet properly.	12

Index

A

- Accessories10
- Adjusting the earpiece volume ...36
- Antenna13
- Area Message78,81

B

- Battery level13
- Battery pack10,11,12

C

- Camera63
 - Recording a Movie67
 - Taking a Photo66
- Cell phone etiquette1
- Cell phone features2
- Character input37
 - Character entry mode37
- Charging the battery pack12
- Checking charges77
- C-mail60
 - C-mail safe block function60
 - Creating and sending61
 - Reading62

D

- Desktop holder10,12
- Disaster Message Board Service ...6
- Display11,21
- Domain23
- Downloading Chaku-Uta®74

E

- E-mail50
 - Attaching images (photos or movies) ...70
 - Creating and sending51
 - Incoming mail54
 - Initial settings22
 - Reading54
 - Replying58
 - Viewing attached images56

- E-mail address22
 - Changing23
 - Entering39
- Entering characters37
 - Entering characters from the same key ...38
- Entering pictograms41
- Extra large characters25
- EZ Navi Walk79,82
 - Current Mail79
 - Current Map79
 - Go Home79,83
 - Going-Out Menu79
 - My Spot79,82
- EZweb71
 - Accessing sites72
 - Initial settings22
 - Top menu72,73

I

- Images (photos or movies)
 - Attaching to e-mail70
 - Photo Mail Service70
- Incoming history28
- Incoming indicator11
- Indicators21
- Initial settings17,22
- Internet71
 - Sites72,73

K

- Key assignments14

L

- Language18
- Launcher menu19
- Learning the basics14
- Limit Mode84
 - Changing the password84
 - Checking the status of use89
 - Setting the use limit86
 - Turning on and off88
- Loud Volume36

M

Mail	
C-mail	60
E-mail	50
Manner mode	30
Movies	
Attaching to e-mail	70
Photo Mail Service	70
Recording	67
Viewing	69

N

Names of parts	11
----------------------	----

O

One-ring calls	29
One-touch Text Size Switching	55
Option menu	20
Outgoing history	28

P

Pair Function	47
Making a call to a pair person	48
Registering a pair person	47
Sending a mail to a pair person	49
Password	16
Phone (call)	
Answering	27
Making	26
Redialing	28
184/186	26
Phone book	42
Dialing	44
Editing	45
Saving	42
Saving a phone number from incoming or outgoing history	46
Phone number	22
Photo Mail Service	70
Photos	
Attaching to e-mail	70
Photo Mail Service	70
Taking	66
Viewing	69
PIN	16

Playback

Voice memo	32
Position Search	78,80
Power supply	
Turning off power	13
Turning on power	13

R

Ring tones

Changing the type	33
Changing the volume	35

S

Signal	13
Sites	72,73
Bookmarking	76
Viewing from bookmarks	77
Smart Mode	90
Creating and sending e-mail and c-mail messages	96
Entering	90
Exiting	91
Saving a phone book entry	94
Using the camera	98
Viewing the Smart menu	92
Soft key	11,15
Spam	57
Standby screen	13
Sub display	11,21

V

Viewing

Movies	69
Photos	69
Voice memo	
Playback	32
Turning on	31

W

Warp function key	11,15
-------------------------	-------

For inquiries, call:

au Customer Service Center (General Information)

From regular phones:

 **0077-7-111**

フリーコール

(toll free)

From **au** cellphones:

157 area code not required

(toll free)

Pressing "zero" will connect you to an operator,
after calling "157" on your au cellphone.



モバイル・リサイクル・ネットワーク

携帯電話・PHSのリサイクルにご協力を。
Cellphone and PHS operators collect and
recycle unused telephones, batteries and
battery chargers at stores bearing the 
logo regardless of brand and
manufacturer to protect the environment
and reuse valuable resources.

Sales: KDDI CORPORATION・

OKINAWA CELLULAR TELEPHONE COMPANY

Manufactured by:

TOSHIBA CORPORATION

October 2005 Edition

Read this code for
an easy access to
au Online Manual.

