


Welcome	Phone Layout	Phone Layout	Brief Intro to the Phone
<p>About your phone</p> <p>Thank you for purchasing this Micromax mobile device. You are now the proud owner of Micromax X104 which offers a rich array of exciting features designed to transform your mobile experience.</p> <p>The X104 offers you the following exciting features:</p> <ul style="list-style-type: none"> □ Dual SIM □ FM Radio □ Digital Camera □ Video Player □ Music Player and Sound recorder □ Marathon Battery □ LED Torch □ Theft Tracker □ Privacy Lock □ Bluetooth and much more <p>Copyright This manual may not be reproduced, distributed or translated in part or in whole in any form or any means without the prior written permission of Micromax Informatics Ltd.</p> <p>Disclaimer The colors and specifications shown/mentioned in the user manual may differ from the actual product. Images shown are for representation purpose only. Other product logos and company names mentioned herein may be trademarks or trade names of their respective owners.</p> <p style="text-align: center;">1</p>	<p>Keys and Parts (Front and Back)</p>  <p>1. Receiver 2. Display Screen 3. Call 1 key (SIM 1) 4. Call 2 key (SIM 2) 5. Keypads 6. Main menu (Center) key</p> <p>7. Back key 8. End/Power key 9. Navigation keys 10. Camera</p> <p style="text-align: center;">2</p>	<p>SIM Card/Memory Card Insertion</p>  <p style="text-align: center;">3</p>	<p>Icons on the main screen</p> <p>Basic Operation</p> <p>1. Switch on/Off Insert SIM card, battery, restore the battery cover and press the End/Power key for a few seconds to turn on your phone. Press the End/power key for a few seconds to turn off your device.</p> <p>3. Dial a call Enter a complete phone number, or access the desired contact number from the Phonebook, press call 1/call 2 key to dial. To make an international call, tap "*" key twice till "+*" displays on the screen. Next add the country prefix "+*" e.g. +62 represents Indonesia. Enter the desired phone number, and press the call 1 or call 2 key.</p> <p>4. Adjust Call volume When engaged in a call, you can press Right or Left key to adjust the volume.</p> <p>5. Answer a call Press call 1/call 2 key to answer an incoming call; press End/Power key to reject the call.</p> <p>6. Call Time Reminder Menu> Settings> Call Settings> Common Call Settings> Call Time Reminder. During a call, you can make your phone remind you with a beep after a specified time (1-3000 seconds countdown).</p> <p style="text-align: right;">www.micromaxinfo.com</p> <p style="text-align: center;">4</p>

<p>7. Lock Your phone from Unauthorised Use The mobile phone allows you to lock your phone from unauthorized use.</p> <p>A. Go to Settings > Security settings > Phone security > SIM1/SIM2 Security> Phone lock.</p> <p>B. Set the Phone lock status to ON.</p> <p>C. Change the Phone lock password by providing the correct old password and the desired new password.</p> <p>Each time you switch on the mobile, you need to provide the password you had set. The default password to use this feature is 0000 (You can change this as required).</p> <p>8. Track Your Mobile Menu> Settings> Security Settings> Theft Tracker You can track your phone in case of loss or theft by activating the Theft tracker mode and configuring an alternate number for receiving messages from the unauthorized user's SIM.</p> <p>9. Privacy for messages, phonebook and call logs</p> <p>a. Go to Menu> Settings> Security Settings> Privacy Lock</p> <p>b. Enter the default password 0000 to set the privacy lock.</p> <p>c. Select and enable the desired objects to protect and save the choice. Each time you access the protected feature such as messages, you will be asked for the password. Note: You can also change the default password to a password of your choice. The new password will be required to access the protected objects (messages/phonebook/call logs).</p> <p style="text-align: center;">5</p>	<p>Frequently Asked Questions</p> <p>1. How do I lock/unlock the phone's keypad?</p> <p>a. To lock: Press center key and "*" key to immediately lock the phone. b. To set auto lock timing, go to Settings > Security settings > Auto Keypad lock and choose the timings and then On/Off as desired. c. To unlock: When your phone is in sleep mode, press the Center key and the "*" key to unlock.</p> <p>2. How do I activate the Silent mode? In standby mode, press and hold "F" key until silent mode is activated; press and hold "F" key again to activate the previous mode.</p> <p>3. Is there a security code to lock/unlock your Phone? Yes. The default security code to unlock the phone is 0000.</p> <p>Safety Guidelines</p> <p>Please follow these simple guidelines for safety: .</p> <p>SAR Information</p> <ul style="list-style-type: none"> □ Your phone is designed not to exceed the limits of emission of radio waves recommended by international guidelines. □ SAR (specific absorption rate) is the unit of body-absorbed RF energy when the phone is in use. □ The Highest SAR value of the handset is 0.927 W/kg(head) and 0.745 W/kg (body) averaged over 1 gm of human tissue. <p style="text-align: center;">6</p>	<p>SAR Recommendations</p> <ul style="list-style-type: none"> □ Use a wireless hands-free system (headphone, headset with a low power bluetooth emitter). □ Please keep your calls short and use SMS whenever convenient. This advice applies especially to children, adolescents and pregnant women. □ Prefer to use your cell phone when the signal quality is good. □ People having active medical implants should preferably keep the cell phone at least 15 cm away from the implant. □ Maintain a preferable distance of 15 mm from the device. <p>Safe Driving</p> <ul style="list-style-type: none"> □ Do not use the phone while driving. When you have to use the phone, please use the personal hands-free kit. <p>During Flight</p> <ul style="list-style-type: none"> □ Flight is influenced by interference caused by the phone. It is illegal to use a phone on the airplane. Please turn off your phone during flight. <p>In Hospitals</p> <ul style="list-style-type: none"> □ Your Phone's radio waves may interfere with the function of inadequately shielded medical devices. Consult a physician or the manufacturer of the medical device to determine whether they are adequately shielded from external RF energy. Switch off your device when regulations posted instruct you to do so. □ To avoid potential interference with implanted medical devices such as a pacemaker or cardioverter defibrillator: <ul style="list-style-type: none"> □ Always keep your phone at least 15.3 centimetres (6 inches) from the medical device □ Do not carry the wireless device in a breast pocket. □ Turn off the phone if there is any reason to suspect that interference is taking place. <p style="text-align: center;">7</p>	<ul style="list-style-type: none"> □ Follow the manufacturer directions for the implanted medical device. <p>Unsafe Areas</p> <ul style="list-style-type: none"> □ Please turn off your phone when you are close to a gas station or in the vicinity of any place where fuel and chemical preparations, or any other dangerous goods are stored. <p>Taking Care of Your Device</p> <ul style="list-style-type: none"> □ Keep the device dry. Precipitation, humidity, and all types of liquids or moisture can rust electronic circuits. □ Do not use or store the device in dusty, dirty areas. Its moving parts and electronic components may get damaged. □ Do not store the device in high or cold temperature as it can shorten the life of electronic devices and damage batteries. □ Do not attempt to repair the phone by yourself other than our authorized service agents/center as this goes against the warranty rules. □ Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and fine mechanics. □ Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the device. Only use a soft, clean, dry cloths to clean the surface of the device. □ Do not store your device near magnetic fields for extended period of time. □ Use manufacturer approved batteries, chargers, accessories and supplies. Micromax will not be held responsible for user's safety when using unapproved accessories or supplies. <p>Disclaimer Micromax keeps the right to make modifications to any of the content here in this User Guide without prior notice. The content of this manual may vary from the actual content displayed in the mobile phone. In such a case, the latter shall govern.</p> <p style="text-align: center;">8</p>	 <p style="text-align: center;">X104 User Guide</p>
---	---	---	---	--